


Metrologic Configuration Bar Codes


Please scan the codes in the numbered order.

1. Enter Program Mode



999999

6. Configuration Code 4



818440

2. Internal Low Speed USB Defaults




999941

7. Configuration Code 5




8188100

3. Configuration Code 1



81601520

8. Exit Program Mode




999999

4. Configuration Code 2



81621660

5. Configuration Code 3



816680