CipherLab

Reference Manual

Software Trigger

For Android™ 6.0

RS30
RS31
9700A
RS50

Version 1.00

Copyright © 2017 CIPHERLAB CO., LTD.
All rights reserved

The software contains proprietary information of its owner; it is provided under a license agreement containing restrictions on use and disclosure and is also protected by copyright law. Reverse engineering of the software is prohibited.

Due to continued product development, this information may change without notice. The information and intellectual property contained herein is confidential between the owner and the client and remains the exclusive property of the owner. If having any problems in the documentation, please report them to us in writing. The owner does not warrant that this document is error-free.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior written permission of the owner.

For product consultancy and technical support, please contact the local sales representative. Also, visit our website for more information.

All brand, logo, product and service, and trademark names are the property of their registered owners.

Google, Google Play, Android and other marks are trademarks of Google Inc.

The editorial use of these names is for identification as well as to the benefit of the owners, with no intention of infringement.

CIPHERLAB logo is a registered trademark of CIPHERLAB CO., LTD. All other brands, products and services, and trademark names are the property of their registered owners. The editorial use of these names is for identification as well as to the benefit of the owners, with no intention of infringement.

CIPHERLAB CO., LTD.
Website: http://www.CipherLab.com

RELEASE NOTES


Version	Date	Notes
1.00	Apr 27, 2017	Initial release

CONTENTS

RELEASE NOTES 3
INTRODUCTION 5
SETUP 6
1.1 Launch Software Trigger 7
1.2 Exit Software Trigger 10
1.3 Check Application Version 11

INTRODUCTION

Software Trigger is an application running on mobile device. Serving as a real trigger key, it always floats on top of all other programs for convenient trigger control of the bardcode scanner; by tapping and holding this virtual button, the device will keep casting a red beam to scan the code.



Chapter 1

SETUP

This chapter guides to the launch of **Software Trigger**, a preloaded App on your device. This chapter also covers the 1st launch of the application.


IN THIS CHAPTER

1.1 Launch Software Trigger 7
1.2 Exit Software Trigger..... 10
1.3 Check Application Version 11


1.1 LAUNCH SOFTWARE TRIGGER

To launch Software Trigger:


1) Tap **All Apps** button on **Home** screen , and tap on **Software Trigger** icon .
2) **Software Trigger** opens showing the following screen. When you enter this application, the scanner is disabled and not yet triggered, as the "**Stop**" button shows.




3) Select the size of the button.




4) Tap "**Start**" to enable the button. You can check "**Auto start software trigger after startup**" to have this application automatically launch right after the device starts up.



5) An always-accessible software keys will appear on your screen.




You can also drag the button to the position on the screen where you feel easy to control the trigger.



1.2 EXIT SOFTWARE TRIGGER

To disable this key, enter **SoftwareTrigger** application screen, and tap "**Stop**".



1.3 CHECK APPLICATION VERSION

To check the version number of current Software Trigger application, on the screen, tap **More** and then **About**.

