


CONFIGURATION GUIDE

NA, EMEA, APAC: ENGLISH

CR2300
CR2600 (XHD)
CR3600 (DPM)



CONFIGURATION GUIDE: VERSION 13
SUPPORTED FIRMWARE: READERS 0956+, MODEM 2000+
RELEASE DATE: NOVEMBER 2014



www.codecorp.com



User Manuals



[YouTube.com/codecorporation](https://www.youtube.com/codecorporation)

code
ADVANCED BARCODE READERS

Table of Contents

Bluetooth Settings	7
Bluetooth Radio Disconnect (Reconnect via QuickConnect Code)	7 (A2)
Bluetooth Auto Reconnect On - Default.....	7 (A3)
Bluetooth Auto Reconnect Off.....	7 (A4)
Bluetooth Radio Out of Range Beep On (CR2300 Default).....	7 (B1)
Bluetooth Radio Out of Range Beep and Vibrate Off - Default (CR2600, CR3600).....	7 (B2)
Bluetooth Radio Out of Range Beep and Vibrate On (CR2600, CR3600).....	7 (B3)
Bluetooth Radio Out of Range Vibrate On (CR2600, CR3600)	7 (B4)
Batch Mode Settings.....	7-8
Batch Mode Disable - Default	7 (C2)
Batch Mode Enable - Log Only	7 (C3)
Batch Mode Enable - Send and Log.....	7 (C4)
Batch Mode Auto Transfer Buffer Memory On	7 (D1)
Batch Mode Auto Transfer Buffer Memory Off	7 (D2)
Batch Mode Transfer All Data and Images in Memory	7 (D3)
Batch Mode Transfer Only Unsent Data in Memory.....	7 (D4)
Delete Buffered Scan Data	7 (E1)
USB Keyboard Mode - Batch Mode Only	7 (E2)
USB Virtual COM - 1 Way Mode - Batch Mode Only	7 (E3)
USB Speed - High Speed - Default Batch Mode Only	7 (E4)
USB Speed - Full Speed - Batch Mode Only.....	8 (A1)
General Modem Settings	8
Preemptive Mode On.....	8 (A3)
Preemptive Mode Off - Default.....	8 (A4)
Reader Paging On - Default	8 (B1)
Reader Paging Off	8 (B2)
General Reading Mode Settings	8
Continuous Scan Both Imagers On	8 (B4)
Continuous Scan Off - Default.....	8 (C1)
Cart Charger Motion Detection On	8 (C2)
Cart Charger Motion Detection Off - Default	8 (C3)
Anti-Glare On (CR2600, CR3600).....	8 (C4)
Anti-Glare Off - Default (CR2600, CR3600)	8 (D1)
Mirroring On.....	8 (D2)
Mirroring Off - Default.....	8 (D3)
Targeting On - Default	8 (D4)
Targeting Off	8 (E1)
Cell Phone Reading Enhancement On	8 (E2)
Cell Phone Reading Enhancement Off - Default.....	8 (E3)
Data Formatting (Prefix/Suffix) Settings.....	9-10
Erase Prefix & Suffix Data - Default	9 (A2)
Erase Prefix Data - Default.....	9 (A3)
Erase Suffix Data - Default	9 (A4)
Prefix AIM ID On	9 (B1)
Prefix AIM ID Off - Default.....	9 (B2)
Prefix Carriage Return Line Feed (RS232 Mode Only).....	9 (B3)
Prefix Comma.....	9 (B4)
Prefix Space.....	9 (C1)
Prefix Tab (USB Keyboard Mode Only)	9 (C2)
Prefix Tab (RS232 Mode Only)	9 (C3)
Suffix Carriage Return (RS232 Mode Only)	9 (C4)
Suffix Carriage Return Line Feed (RS232 Mode Only)	9 (D1)
Suffix Comma.....	9 (D2)
Suffix Enter (USB Keyboard Mode Only)	9 (D3)
Suffix Line Feed (RS232 Mode Only).....	9 (D4)

Table of Contents

Suffix Space.....	9 (E1)
Suffix Tab (USB Keyboard Mode Only)	9 (E2)
Suffix Tab (RS232 Mode Only).....	9 (E3)
Translate all Characters to Uppercase On	9 (E4)
Translate all Characters to Uppercase Off - Default	10 (A1)
Symbologies.....	10-15
Australian Post On	10 (A3)
Australian Post Off - Default	10 (A4)
Aztec On - Default	10 (B1)
Aztec Off	10 (B2)
Aztec Inverse On.....	10 (B3)
Aztec Inverse & Normal On	10 (B4)
Codabar On - Default.....	10 (C1)
Codabar Off.....	10 (C2)
Codablock F On	10 (C3)
Codablock F Off - Default	10 (C4)
Code 11 On.....	10 (D1)
Code 11 Off - Default.....	10 (D2)
Code 11 Checksum Stripped from Result On	10 (D3)
Code 128 On - Default	10 (D4)
Code 128 Off	10 (E1)
Code 32 (Italian Pharmacode) On.....	10 (E2)
Code 32 (Italian Pharmacode) Off - Default.....	10 (E3)
Code 39 On - Default	11 (A1)
Code 39 Off	11 (A2)
Code 39 Checksum On.....	11 (A3)
Code 39 Checksum Off - Default	11 (A4)
Code 39 Checksum Stripped from Result On	11 (B1)
Code 39 Extended Full ASCII On.....	11 (B2)
Code 39 Extended Full ASCII Off - Default	11 (B3)
Code 93 On - Default	11 (C1)
Code 93 Off	11 (C2)
Composite On.....	11 (C3)
Composite Off - Default	11 (C4)
Data Matrix Inverse On - Default.....	11 (D1)
Data Matrix Inverse Off.....	11 (D2)
Data Matrix Standard and Rectangle (Defaulted On and Cannot be Disabled)	
All GS1 DataBar On - Default.....	11 (D3)
All GS1 DataBar Off	11 (D4)
GS1 DataBar Omnidirectional and GS1 DataBar Truncated On	11 (E1)
GS1 DataBar Omnidirectional and GS1 DataBar Truncated Off.....	11 (E2)
GS1 DataBar Expanded On.....	11 (E3)
GS1 DataBar Expanded Off	11 (E4)
GS1 DataBar Expanded Stacked On	12 (A1)
GS1 DataBar Expanded Stacked Off	12 (A2)
GS1 DataBar Limited On.....	12 (A3)
GS1 DataBar Limited Off.....	12 (A4)
GS1 DataBar Stacked and GS1 DataBar Omnidirectional On.....	12 (B1)
GS1 DataBar Stacked and GS1 DataBar Omnidirectional Off	12 (B2)
Han Xin On	12 (B3)
Han Xin Off - Default	12 (B4)
Hong Kong 2 of 5 On	12 (C1)
Hong Kong 2 of 5 Off - Default	12 (C2)
IATA 2 of 5 On (IATA 2 of 5 is a Variant of Straight 2 of 5; to Enable IATA 2 of 5 Scan Straight 2 of 5 On)	
IATA 2 of 5 Off (IATA 2 of 5 is a Variant of Straight 2 of 5; to Disable IATA 2 of 5 Scan Straight 2 of 5 Off)	
Int 2 of 5 On - Default	12 (C3)
Int 2 of 5 Off.....	12 (C4)
Int 2 of 5 Checksum On	12 (D1)
Int 2 of 5 Checksum Off - Default	12 (D2)
Int 2 of 5 Checksum Stripped from Result On.....	12 (D3)



Table of Contents

Japan Post On	12 (D4)
Japan Post Off - Default	12 (E1)
KIX (Dutch Post) Code On.....	12 (E2)
KIX (Dutch Post) Code Off - Default.....	12 (E3)
Korean Post On	13 (A1)
Korean Post Off - Default	13 (A2)
Maxicode On	13 (A3)
Maxicode Off - Default	13 (A4)
Matrix 2 of 5 On.....	13 (B1)
Matrix 2 of 5 Off - Default	13 (B2)
Micro PDF417 On	13 (B3)
Micro PDF417 Off - Default.....	13 (B4)
MSI Plessey On	13 (C1)
MSI Plessey Off -Default	13 (C2)
NEC 2 of 5 On	13 (C3)
NEC 2 of 5 Off - Default.....	13 (C4)
PDF417 On - Default.....	13 (D1)
PDF417 Off	13 (D2)
Pharmacode On.....	13 (D3)
Pharmacode Off - Default	13 (D4)
Pharmacode Normal Barcode Decoding (Left to Right)	13 (E1)
Pharmacode Reverse Barcode Decoding (Right to Left).....	13 (E2)
All QR Code On	14 (A1)
All QR Code Off.....	14 (A2)
Standard QR Code On - Default.....	14 (A3)
Standard QR Code Off.....	14 (A4)
Straight 2 of 5 On.....	14 (B1)
Straight 2 of 5 Off - Default.....	14 (B2)
Telepen On.....	14 (B3)
Telepen Off - Default.....	14 (B4)
Trioptic On	14 (C1)
Trioptic Off - Default	14 (C2)
UK Plessey On	14 (C3)
UK Plessey Off - Default.....	14 (C4)
UK Royal Mail On	14 (D1)
UK Royal Mail Off - Default	14 (D2)
UPC On - Default.....	14 (D3)
UPC Off	14 (D4)
UPC E Expansion On.....	14 (E1)
UPC E Expansion Off - Default.....	14 (E2)
UPC Supplemental On	14 (E3)
UPC Supplemental Off - Default	14 (E4)
UPU ID-Tag On.....	15 (A1)
UPU ID-Tag Off - Default.....	15 (A2)
USPS Intelligent Mail/IMB/4-State CB On	15 (A3)
USPS Intelligent Mail/IMB/4-State CB Off - Default	15 (A4)
USPS Planet On	15 (B1)
USPS Planet Off - Default	15 (B2)
USPS Postnet On	15 (B3)
USPS Postnet Off - Default.....	15 (B4)
Direct Part Mark Reading Mode Settings (CR3600 DPM).....	15
DPM (All) Off	15 (C2)
DPM (Dot Peen and Laser-Etched) On.....	15 (C3)
DPM (Dot Peen Only) On	15 (C4)
DPM (Laser-Etched Only) On	15 (D1)
Keyboard Language Settings.....	15
US English Keyboard Mapping - No Leading 0.....	15 (D3)
US English Keyboard Mapping - with Leading 0 for Non Printable ASCII.....	15 (D4)



Table of Contents

Keyboard Control Characters for Non Printable ASCII	15 (E1)
Belgium Keyboard	15 (E2)
French Keyboard	15 (E3)
German Keyboard	15 (E4)
Japanese Keyboard	16 (A1)
Spanish (Latin America) Keyboard.....	16 (A2)
Swiss Keyboard	16 (A3)
Universal Keyboard Mapping.....	16 (A4)
Operating System Settings.....	16
Alternative Operating System (Linux/Mac) On	16 (B2)
Alternative Operating System (Linux/Mac) Off - Default	16 (B3)
USB Settings (Non-Batch Mode)	16
USB Keyboard Mode - Default	16 (C2)
USB Downloader Mode.....	16 (C3)
USB HID POS Mode	16 (C4)
USB Virtual COM Mode.....	16 (D1)
RS232 Settings (CodeXML M3 Modem Only)	16
RS232 Communication Mode	16 (D3)
RS232 Interface - 9600 Baud Rate	16 (D4)
RS232 Interface - 19200 Baud Rate	16 (E1)
RS232 Interface - 38400 Baud Rate	16 (E2)
RS232 Interface - 57600 Baud Rate	16 (E3)
RS232 Interface - 115200 Baud Rate - Default.....	16 (E4)
Reader Feedback Settings	16-17
Beep On Vibrate On - Default (CR2600, CR3600)	16 (A2)
Beep Off Vibrate Off (CR2600, CR3600)	16 (A3)
Beep Off Vibrate On (CR2600, CR3600)	16 (A4)
Beep On Vibrate Off (CR2600, CR3600)	17 (B1)
Beep Volume 100% - Default	17 (B2)
Beep Volume 67%	17 (B3)
Beep Volume 33%	17 (B4)
Beep Volume 0%	17 (C1)
Scan Delay.....	17
Duplicate Scan Disabled - Default	17 (C3)
1 Second Duplicate Scan Delay	17 (C4)
2 Second Duplicate Scan Delay	17 (D1)
3 Second Duplicate Scan Delay	17 (D2)
5 Second Duplicate Scan Delay	17 (D3)
10 Second Duplicate Scan Delay	17 (D4)
30 Second Duplicate Scan Delay	17 (E1)
1 Hour Duplicate Scan Delay	17 (E2)
1 Day Duplicate Scan Delay.....	17 (E3)
Power Settings	18
Power Off in 1 Hour	18 (A2)
Power Off in 2 Hours	18 (A3)
Power Off in 4 Hours	18 (A4)
Miscellaneous Settings.....	18
Read Both Wide and High Density Field - Default	18 (B2)
Read High Density Field Only	18 (B3)
Read Wide Field Only.....	18 (B4)
Handle Trigger Take Picture	18 (C1)
Main Left (CR3600) / Bottom (CR2300/CR2600) Button Take Picture	18 (C2)
Main Right (CR3600) / Top (CR2300/CR2600) Button Take Picture.....	18 (C3)



Table of Contents

Reader/Modem Commands 18

Reader ID and Firmware Version..... 18 (D2)

Modem ID and Firmware Version 18 (D3)

Reader Text Commands On 18 (D4)

Reader Text Commands Off - Default18 (E1)

Reset, Clear, and Save Reader Settings.....18-19

Reset Reader to RF Factory Defaults.....18 (E3)

Clear All JavaScript Rules.....18 (E4)


Clear All Stored Data and Images19 (A1)

Save All Reader Settings19 (A2)

Reboot Reader.....19 (A3)

CR2300/CR2600/CR3600 Configuration Guide

NOTE: The configuration change will take effect immediately and be saved to memory.

Bluetooth Settings	Bluetooth Radio Disconnect (Reconnect via QuickConnect Code)	Bluetooth Auto Reconnect On - Default	Bluetooth Auto Reconnect Off
	 M10177_01 A2	 M10365_01 A3	 M10364_01 A4
Bluetooth Radio Out of Range Beep On (CR2300 Default)	Bluetooth Radio Out of Range Beep and Vibrate Off - Default (CR2600 & CR3600)	Bluetooth Radio Out of Range Beep and Vibrate On (CR2600 & CR3600)	Bluetooth Radio Out of Range Vibrate On (CR2600 & CR3600)
 M10173_01 B1	 M10176_01 B2	 M10175_01 B3	 M10174_01 B4
Batch Mode Settings	Batch Mode Disable - Default	Batch Mode Enable - Log Only	Batch Mode Enable - Send and Log
	 M10187_04 C2	 M10188_04 C3	 M10186_04 C4
Batch Mode Auto Transfer Buffer Memory On	Batch Mode Auto Transfer Buffer Memory Off	Batch Mode Transfer All Data and Images in Memory	Batch Mode Transfer Only Unsent Data in Memory
 M10307_01 D1	 M10308_01 D2	 M10297_01 D3	 M10305_01 D4
Delete Buffered Scan Data	USB Keyboard Mode - Batch Mode Only	USB Virtual COM - 1 Way Mode - Batch Mode Only	USB Speed - High Speed - Batch Mode Only - Default
 M10306_01 E1	 M10200_01 E2	 M10005_01 E3	 M10160_01 E4

CR2300/CR2600/CR3600 Configuration Guide

NOTE: The configuration change will take effect immediately and be saved to memory.

USB Speed - Full Speed - Batch Mode Only M10161_01 A1	General Modem Settings		Preemptive Mode On M10225_01 A3	Preemptive Mode Off - Default M10226_01 A4
Reader Paging On - Default M10155_01 B1	Reader Paging Off M10156_01 B2	General Reading Mode Settings		Continuous Scan Both Imagers On M10012_02 B4
Continuous Scan Off - Default M10011_01 C1	Cart Charger Motion Detection - On M10373_01 C2	Cart Charger Motion Detection - Off M10374_02 C3	Anti-Glare On (CR2600, CR3600) M10352_01 C4	
Anti-Glare Off - Default (CR2600, CR3600) M10433_01 D1	Mirroring On M10125_01 D2	Mirroring Off - Default M10124_02 D3	Targeting On - Default M10153_01 D4	
Targeting Off M10154_01 E1	Cell Phone Reading Enhancement On M10163_01 E2	Cell Phone Reading Enhancement Off - Default M10162_01 E3	Intentionally Blank E4	

CR2300/CR2600/CR3600 Configuration Guide

NOTE: The configuration change will take effect immediately and be saved to memory.

Data Formatting (Prefix / Suffix) Settings	Erase Prefix & Suffix Data - Default	Erase Prefix Data - Default	Erase Suffix Data - Default	
	 M10135_01	 M10126_01	 M10130_01	
	A2	A3	A4	
	Prefix AIM ID On	Prefix AIM ID Off - Default	Prefix Carriage Return Line Feed (RS232 Mode Only)	Prefix Comma
	 M10199_01	 M10198_01	 M10405_01	 M10127_01
B1	B2	B3	B4	
Prefix Space	Prefix Tab (USB Keyboard Mode Only)	Prefix Tab (RS232 Mode Only)	Suffix Carriage Return (RS232 Mode Only)	
 M10128_01	 M10129_01	 M10319_01	 M10320_01	
C1	C2	C3	C4	
Suffix Carriage Return Line Feed (RS232 Mode Only)	Suffix Comma	Suffix Enter (USB Keyboard Mode Only)	Suffix Line Feed (RS232 Mode Only)	
 M10322_01	 M10131_01	 M10134_01	 M10321_01	
D1	D2	D3	D4	
Suffix Space	Suffix Tab (USB Keyboard Mode Only)	Suffix Tab (RS232 Mode Only)	Translate all Characters to Uppercase On	
 M10132_01	 M10133_01	 M10323_01	 M10220_03	
E1	E2	E3	E4	

CR2300/CR2600/CR3600 Configuration Guide

NOTE: The configuration change will take effect immediately and be saved to memory.

Translate all Characters to Uppercase Off - Default  M10426_02 A1	Symbologies	Australian Post On  M10288_02 A3	Australian Post Off - Default  M10289_02 A4
Aztec On - Default  M10018_01 B1		Aztec Off  M10019_01 B2	Aztec Inverse On  M10020_01 B3
Codabar On - Default  M10022_01 C1	Codabar Off  M10023_01 C2	Codablock F On  M10027_01 C3	Codablock F Off - Default  M10026_01 C4
Code 11 On  M10029_01 D1	Code 11 Off - Default  M10028_01 D2	Code 11 Checksum Stripped from Result On  M10031_01 D3	Code 128 On - Default  M10044_01 D4
Code 128 Off  M10045_01 E1	Code 32 (Italian Pharmacode) On  M10239_02 E2	Code 32 (Italian Pharmacode) Off - Default  M10238_02 E3	Intentionally Blank E4

CR2300/CR2600/CR3600 Configuration Guide

Code 39 On - Default  M10033_02 A1	Code 39 Off  M10034_02 A2	Code 39 Checksum On  M10036_01 A3	Code 39 Checksum Off - Default  M10035_01 A4
Code 39 Checksum Stripped from Result On  M10037_01 B1	Code 39 Extended Full ASCII On  M10039_01 B2	Code 39 Extended Full ASCII Off - Default  M10038_01 B3	Intentionally Blank B4
Code 93 On - Default  M10042_01 C1	Code 93 Off  M10043_01 C2	Composite On  M10047_01 C3	Composite Off - Default  M10046_01 C4
Data Matrix Inverse On - Default  M10051_03 D1	Data Matrix Inverse Off  M10050_03 D2	All GS1 DataBar On - Default  M10054_01 D3	All GS1 DataBar Off  M10055_01 D4
GS1 DataBar Omnidirectional and GS1 DataBar Truncated On  M10057_03 E1	GS1 DataBar Omnidirectional and GS1 DataBar Truncated Off  M10355_02 E2	GS1 DataBar Expanded On  M10059_03 E3	GS1 DataBar Expanded Off  M10417_02 E4



CR2300/CR2600/CR3600 Configuration Guide

NOTE: The configuration change will take effect immediately and be saved to memory.

GS1 DataBar Expanded Stacked On  M10357_02 A1	GS1 DataBar Expanded Stacked Off  M10356_02 A2	GS1 DataBar Limited On  M10056_03 A3	GS1 DataBar Limited Off  M10354_02 A4
GS1 DataBar Stacked and GS1 DataBar Stacked Omnidirectional On  M10058_03 B1	GS1 DataBar Stacked and GS1 DataBar Stacked Omnidirectional Off  M10353_03 B2	Han Xin On  M10248_01 B3	Han Xin Off - Default  M10249_01 B4
Hong Kong 2 of 5 On  M10079_01 C1	Hong Kong 2 of 5 Off - Default  M10078_02 C2	Int 2 of 5 On - Default  M10060_01 C3	Int 2 of 5 Off  M10061_01 C4
Int 2 of 5 Checksum On  M10235_01 D1	Int 2 of 5 Checksum Off - Default  M10234_01 D2	Int 2 of 5 Checksum Stripped from Result On  M10065_01 D3	Japan Post On  M10292_02 D4
Japan Post Off - Default  M10293_02 E1	KIX (Dutch Post) Code On  M10290_02 E2	KIX (Dutch Post) Code Off - Default  M10291_02 E3	Intentionally Blank E4

 D004482_13 CR2300 CR2600 CR3600 Configuration Guide *For questions regarding reader configuration contact support@codecorp.com.* 13

CR2300/CR2600/CR3600 Configuration Guide

NOTE: The configuration change will take effect immediately and be saved to memory.

All QR Code On  M10101_02 A1	All QR Code Off  M10351_03 A2	Standard QR Code On - Default  M10095_03 A3	Standard QR Code Off  M10096_02 A4
Straight 2 of 5 On  M10241_01 B1	Straight 2 of 5 Off - Default  M10240_01 B2	Telepen On  M10103_01 B3	Telepen Off - Default  M10104_01 B4
Trioptic On  M10041_01 C1	Trioptic Off - Default  M10040_01 C2	UK Plessey On  M10237_02 C3	UK Plessey Off - Default  M10236_02 C4
UK Royal Mail On  M10294_02 D1	UK Royal Mail Off - Default  M10295_02 D2	UPC On - Default  M10105_01 D3	UPC Off  M10106_01 D4
UPC E Expansion On  M10108_01 E1	UPC E Expansion Off - Default  M10107_01 E2	UPC Supplemental On  M10110_01 E3	UPC Supplemental Off - Default  M10109_01 E4



CR2300/CR2600/CR3600 Configuration Guide

NOTE: The configuration change will take effect immediately and be saved to memory.

UPU ID-Tag On  M10360_02 A1	UPU ID-Tag Off - Default  M10361_02 A2	USPS Intelligent Mail/IMB/ 4-State CB On  M10286_02 A3	USPS Intelligent Mail/IMB/ 4-State CB Off  M10287_02 A4
USPS Planet On  M10284_02 B1	USPS Planet Off - Default  M10285_02 B2	USPS Postnet On  M10282_02 B3	USPS Postnet Off - Default  M10283_02 B4
Direct Part Mark Reading Mode Settings (CR3600 DPM)	DPM (All) Off  M10369_01 C2	DPM (Dot Peen and Laser-Etched) On  M10372_01 C3	DPM (Dot Peen Only) On  M10370_01 C4
DPM (Laser-Etched Only) On  M10371_01 D1	Reader Keyboard Language Settings	US English Keyboard Mapping - No Leading 0  M10111_01 D3	US English Keyboard Mapping - with Leading 0 for Non Printable ASCII  M10411_01 D4
Keyboard Control Characters for Non Printable ASCII  M10412_01 E1	Belgium Keyboard  M10115_01 E2	French Keyboard  M10414_01 E3	German Keyboard  M10415_01 E4



 D004482_13 CR2300 CR2600 CR3600 Configuration Guide *For questions regarding reader configuration contact support@codecorp.com.* 16


CR2300/CR2600/CR3600 Configuration Guide

NOTE: The configuration change will take effect immediately and be saved to memory.

Reader Feedback Settings	Beep On Vibrate On - Default (CR2600, CR3600)	Beep Off Vibrate Off (CR2600, CR3600)	Beep Off Vibrate On (CR2600, CR3600)
	 M10140_01	 M10143_01	 M10141_01
	A2	A3	A4
Beep On Vibrate Off (CR2600, CR3600)	Beep Volume 100% - Default	Beep Volume 67%	Beep Volume 33%
 M10142_01	 M10197_01	 M10196_01	 M10195_01
B1	B2	B3	B4
Beep Volume 0%	Scan Delay	Duplicate Scan Disabled - Default	1 Second Duplicate Scan Delay
 M10194_01		 M10144_01	 M10145_01
C1		C3	C4
2 Second Duplicate Scan Delay	3 Second Duplicate Scan Delay	5 Second Duplicate Scan Delay	10 Second Duplicate Scan Delay
 M10146_01	 M10147_01	 M10148_01	 M10149_01
D1	D2	D3	D4
30 Second Duplicate Scan Delay	1 Hour Duplicate Scan Delay	1 Day Duplicate Scan Delay	Intentionally Blank
 M10150_01	 M10151_01	 M10152_01	
E1	E2	E3	E4

CR2300/CR2600/CR3600 Configuration Guide

NOTE: The configuration change will take effect immediately and be saved to memory.

Power Settings	Power Off in 1 Hour  M10316_01 A2	Power Off in 2 Hour  M10317_01 A3	Power Off in 4 Hours  M10318_01 A4
	Read Both Wide and High Density Field - Default  M10190_01 B2	Read High Density Field Only  M10183_01 B3	Read Wide Field Only  M10182_01 B4
Handle Trigger Take Picture  M10341_01 C1	Main Left (CR3600) / Bottom (CR2300/CR2600) Button Take Picture  M10340_01 C2	Main Right (CR3600) / Top (CR2300/CR2600) Button Take Picture  M10339_01 C3	Intentionally Blank C4
Reader/Modem Commands	Reader ID and Firmware Version  M10157_01 D2	Modem ID and Firmware Version  M10158_01 D3	Reader Text Commands On  M10137_01 D4
Reader Text Commands Off  M10136_01 E1	Reset, Clear, and Save Reader Settings		Reset Reader to RF Factory Defaults  M10001_03 E3
			Clear All JavaScript Rules  M10139_01 E4

CR2300/CR2600/CR3600 Configuration Guide

NOTE: The configuration change will take effect immediately and be saved to memory.

Clear All Stored Data and Images  M10138_02 A1	Save All Reader Settings  M10159_0 A2	Reboot Reader  M10296_01 A3	Intentionally Blank A4
Intentionally Blank B1	Intentionally Blank B2	Intentionally Blank B3	Intentionally Blank B4
Intentionally Blank C1	Intentionally Blank C2	Intentionally Blank C3	Intentionally Blank C4
Intentionally Blank D1	Intentionally Blank D2	Intentionally Blank D3	Intentionally Blank D4
Intentionally Blank E1	Intentionally Blank E2	Intentionally Blank E3	Intentionally Blank E4

