



Włączenie przycisku

Enter/Exit Configuration Mode




Wyłączenie przycisku


Enter/Exit Configuration Mode



Post Defaults




Post Defaults




* Enable CodeGate



Disable CodeGate



Enter/Exit Configuration Mode



Enter/Exit Configuration Mode

